

Beverage Fountain Instructions

Requirements:

Never hold the fountain by the top or the figurine. Carry it by the bottom bowl only.

Do not lay fountain on its side during transport. Place upright and secure lightly for transport.

Use grounded outlets and heavy duty extension cords only. Do not bypass ground lead on plug.

Do not operate on wet surface or submerge fountain in water.

Do not operate without proper fluid levels in the bottom bowl to avoid damage to the pump.

Operating Instructions:

Place fountain on level and dry surface.

Plug in machine.

Fill fountain half full or at least one gallon before turning on fountain to prime the pump.

Fountain does not chill beverages. Add to the machine already chilled. You may use ice rings or molds to keep chilled. Do not use crushed ice, it will clog the fountain.

Use with clear fruit juice, wine or champagne. Do not use anything with fruit pulp.

Do not run fountain dry.

Unplug fountain when finished. Empty fountain by holding bottom bowl and figurine and slowly pouring out any excess fluid.

Cleaning Instructions:

Place two gallons of warm water with two tablespoons of baking soda in the fountain. Turn on fountain and let run for 10 minutes to dissolve any sugars that have accumulated. Empty fountain of cleaning solution. Wipe fountain bowl with clean damp cloth.

Do not disassemble fountain.

_____ Received By _____ Date