

Funnel Cake Fryer Instructions

Requirements:

Machine must be operated on dedicated and grounded power line.

120volts/1800watts/15amps/1phase

Plug directly into a wall outlet or 15 amp heavy duty extension cord

BE VERY CAREFUL – HOT GREASE!!!

Have fire extinguisher close – do not put water on hot grease

Oil Capacity – 20lbs or 2.5 gallons

Make sure unit is on level operating surface

Add oil – peanut oils and other high viscosity frying oils work best

Turn on unit