

# Popcorn Machine Instructions

## Requirements:

Use only grounded outlets and heavy duty extension cords. Requires minimum 11 amps power.

Place on level surface for proper operation.

## Operating Instructions:

Turn Kettle Heat and Kettle Motor switch to ON

Make test pop by putting 3 kernels of corn and 1oz of oil into the kettle. When these have popped, load kettle with 2oz of oil, 6oz of corn and 1oz of salt.

If using our 8oz or 16oz kits, you can put all of the oil at once. Let it start to melt, then add the pouch of corn kernels and salt.

When the corn has popped, dump the kettle into the popper base.

If preparing multiple batches, allow the kettle to cool and carefully wipe outside of kettle with damp cloth to remove any oil drips.

For best results, prepare 3 – 5 batches of popcorn.

## Cleaning Instructions:

Allow kettle to cool completely.

Unplug popper.

Remove all excess popcorn, kernels and oil from the kettle and popper base.

Wipe out kettle and popper base with soft damp cloth.

Do not submerge in water or place on wet surface.

\_\_\_\_\_ Received By \_\_\_\_\_ Date