

Before plugging your unit in, be sure the source voltage in your area matches the required voltage of your Bubbletron XL. Because line voltage may vary from venue to venue, be sure to plug your unit into a matching wall outlet before attempting to operate.

Filling the Tray Reservoir:

1. Place the Bubbletron XL on a flat level surface.
2. The bubble juice tray is located in the front of the machine. Fill the tray, using premium American DJ® brand bubble juice. Make sure that you do not fill the tray above the designated fill line. Filling above the line will result in damage to the machine. After the usage, please empty the remaining juice to prevent damage as well.

Operation:

With the unit on a flat surface and with the tray filled, flip the power switch to the “ON” position and watch the bubbles come out by the hundreds. Be sure the unit remains in a level position to avoid accidental leaking.

Maintenance:

The frequency of cleaning depends on the environment in which the device operates in: damp, smoky or particularly dirty environments can cause greater accumulation of dirt and or debris in the tank. Clean the external housing of the fixture and the tank at least periodically with a soft cloth to avoid dirt/debris accumulation. **NEVER** use alcohol, solvents, or ammonia-based cleaners.

Remote Operation (Optional):

The unit may be used with the (included) Z-LC3 Wired Remote Control or the (optional) BUBXL-WR Wireless Remote Control. When using a remote, set the power switch to the “OFF” position.

Remote Operation:

1. With the power switch in the “OFF” position, plug the remote control into the unit.
2. Push the power button on the remote to the “ON” position, main power will be indicated by a glowing red LED above the remote power button.

